5.3.2 Recalibration

If the error code displays as the figure 5-7, users should calibrate the throttle **strictly** as below steps.

⚠ Before calibration, please detach the kill switch from the control system.

Figure 5-7

Recalibration process	LCD Displaying
Step1: Long press " ∧ " button for 10s until "CAL FO" displays.	
Step2: Push the throttle to the maximum forward power position, then press "OK" button. "CAL St" will display and "CAL" will be blinking.	
Step3: Pull the throttle to the middle (zero) position where you can hear a click sound, then press "OK"button, "CAL bA" will display and "CAL" will be blinking.	
Step4: Pull the throttle to the maximum backward power position, then press "OK" button. It will return to the main page automatically.	