

4.2 Storage



When the battery is not in use, make sure that the battery's connectors are covered well with the waterproof caps.



Disconnect all connections to the battery and check that all connectors are clean.



Before storage, make sure the battery level is around 45%~50%, and stored at an ambient temperature of 15°C ~ 25°C, relative humidity not more than 75%, clean, dry and ventilated place, to avoid contact with corrosive contact, away from fire and heat sources.



Protect against moisture, dust, water, shock and heat.



Every 6 months of storage, the battery should be recharged with an appropriate ePropulsion charger.