



7 Checklist before Use

1. Ensure the propeller is correctly and firmly mounted on the pod drive.
 2. Ensure the pod drive is correctly and firmly mounted on the boat.
 3. Ensure the remote control and steering wheel are installed in proper position before turning on the power.
 4. Ensure the throttle travels smoothly with no obstacles.
 5. Before connecting the battery, check and make sure there is no poor contacts or defects in cables.
 6. Check and ensure the main switch is able to power on and off normally.
After that, turn off the main switch.
 7. Ensure the battery has enough power.
 8. Ensure the remote control has enough power.
-  Make sure the power cable is dry before connecting it to the battery or powering on the system.

8 Starting the Pod

1. Complete the check list.
2. Remove the kill switch from the remote control.
3. Push the throttle to zero position.
4. Connect the battery with the driver module.
5. Turn on the main switch. When using with NAVY Batteries, please also turn on the batteries by pressing the power button.
6. Press “  ” button to turn on the remote control.
7. Carry out preference setting and battery configuration if necessary.
8. Tie the kill switch to your wrist or life vest, then attach the kill switch on the remote control.
9. Push the throttle slowly to start running.